

**tvc** Controller Manual

---

**TVL195**

ISSUE 7

04/00

**ONIX  
MICROPROCESSOR  
COLLECTIVE  
LIFT CONTROL  
MANUAL**

## CONTENTS

<u>SECTION 1</u>	<u>INTRODUCTION</u>	<u>PAGE</u>
1.1	General	4
1.2	Construction	5
1.3	Overall System Description	5
1.4	Performance Characteristics	6
1.4.1	Electrical	6
1.4.2	Mechanical	7
1.5	Microprocessor System Description	8
<u>SECTION 2</u>	<u>INSTALLATION &amp; COMMISSIONING</u>	
2.1	General	9
2.2	Connector Access	9
2.3	Microprocessor/System Connection	10
2.4	Control Panel Switch-on	10
2.5	Microprocessor Switch-on	11
2.6	Call Entry	11
2.6.1	Accessing and using the Call Entry Sub-Menu	12
2.7	Homing	12
2.8	Timers	12
2.9	Stuck Push Button	12
2.10	Motherboard I/O Designations	13
2.11	Call Designations	14
2.12	I/O Card Designations	15
<u>SECTION 3</u>	<u>OPERATING PROCEDURES</u>	
3.1	Operation of the Controls and Significance of Visual Indicators	19
3.1.1	Power Supply Unit	19
3.1.2	Event Log Card	19
3.1.3	CPU Card	19
3.1.4	I/O Card	19
3.1.5	Audible Indicators	20
3.1.5.1	Engineering Code	20
3.1.5.2	Event Log	20
3.1.5.3	Limited Force Door Closing	20
3.1.5.5	Selfish User Buzzer	20

<b><u>SECTION 3</u></b>	<b><u>OPERATING PROCEDURES</u></b>	<b><u>PAGE</u></b>
<b>3.2</b>	<b>Switches</b>	<b>21</b>
3.2.1	CPU and Configuration Switches	21
3.2.2	RST Switch	22
3.2.3	DDS & PTT Switches	22
3.2.4	Timers	23
3.2.5	Motherboard Features	25
<b>3.3</b>	<b>Normal Control (Simplex)</b>	<b>26</b>
<b>3.4</b>	<b>Fire Control</b>	<b>27</b>
<b>3.5</b>	<b>Service Control (Car Preference)</b>	<b>28</b>
<b>3.6</b>	<b>By-Pass (Weight Switch 95%)</b>	<b>28</b>
<b>3.7</b>	<b>Event Log</b>	<b>29</b>
<b>3.8</b>	<b>Event Messages</b>	<b>29</b>
3.8.1	How to access and use the Event Log Sub Menu	31
3.8.2	Recalling the Event Log	32
3.8.3	Engineers Entry	32
3.8.4	Clearing the Event Log	33
3.8.5	Event Code Description	34
3.8.6	Security Code	45
<b><u>SECTION 4</u></b>	<b><u>TECHNICAL DESCRIPTION</u></b>	
<b>4.1</b>	<b>Motherboard</b>	<b>46</b>
<b>4.2</b>	<b>Power Supply</b>	<b>46</b>
<b>4.3</b>	<b>CPU Card</b>	<b>47</b>
<b>4.4</b>	<b>Watchdog-Loop Flag Monitor</b>	<b>47</b>
<b>4.5</b>	<b>Audible Warning</b>	<b>47</b>
<b>4.6</b>	<b>Pushbuttons</b>	<b>47</b>
<b><u>SECTION 5</u></b>	<b><u>OVERHAUL &amp; REPAIR</u></b>	
<b>5.1</b>	<b>Handling of EPROM'S</b>	<b>49</b>
<b>5.2</b>	<b>Fault Finding Procedures</b>	<b>49</b>
<b><u>SECTION 6</u></b>	<b><u>ILLUSTRATIONS</u></b>	
<b>FIG. 1</b>	<b>Component Positions On Motherboard</b>	<b>53</b>
<b>FIG. 2</b>	<b>General Wiring Schematic</b>	<b>54</b>
<b>FIG. 3</b>	<b>Overview Of Menu System</b>	<b>55</b>
<b>FIG.4</b>	<b>Setting up of Single Floor Run</b>	<b>56</b>

**SECTION 1**

**INTRODUCTION**

		<b><u>PAGE</u></b>
1.1	<b>General</b>	<b>4</b>
1.2	<b>Construction</b>	<b>5</b>
1.3	<b>Overall System Description</b>	<b>5</b>
1.4	<b>Performance Characteristics</b>	<b>6</b>
1.4.1	Electrical	6
1.4.2	Mechanical	7
1.5	<b>Microprocessor System Description</b>	<b>8</b>

## 1.1 GENERAL

The TVC ONIX Microprocessor Lift Control Module is one of a number of modules supplied by TVC which together make up a lift control system. The module is designed using current technology to provide a cost-effective lift control panel whilst maintaining all the safety, reliability and flexibility features associated with Thames Valley products.

In addition to the normal features a number of refinements are included as standard; these include, for example, recognition of a stuck button (which is consequently ignored), LED indication of each incoming and outgoing signal, a display of the lift position and direction of travel and on request displays of certain past and present lift events which are displayed in 'English Language'.

Features provided by the system include:

- a) Fireman Control and Indicator
- b) Special Service Control
- c) Homing
- d) Landing Door Re-open Once
- e) Light Ray Failure
- f) Stuck Button Detection
- g) Differential Door Timing
- h) Advance Call Cancel
- j) Door Close Push
- k) Weight Switch 95%, 110%. and Overload Indicator
- l) Car Call Dumping
- m) Event Message Display (in 'English Language')
- n) Door Opening and Closing Protection
- (o) 3 Wire Indicator System

## 1.2 **CONSTRUCTION**

The system comprises a motherboard onto which a number of printed circuit cards are mounted (see Fig 1.0). Connections to the motor panel are achieved via Molex connectors on the motherboard. Shaft and car wiring are via screw-clamp type terminals also on the motherboard.

The system voltages are derived from a transformer/power supply module mounted on the motor panel and are fed via a wiring loom to the microprocessor motherboard.

## 1.3 **OVERALL SYSTEM DESCRIPTION**

The overall TVC Microprocessor Collective Lift Control System comprises a Microprocessor Unit and a Motor Panel Section plus Shaft and Car wiring.

The overall system is built around the 6809 Microprocessor which is used as the control centre for monitoring and addressing all incoming and outgoing signals to the remainders of the system.

The lift motor operation is controlled by the Motor Panel Section which receives signals from the Microprocessor, such as pilot up, pilot down, pilot high speed, pilot open doors and pilot close doors. The Motor Panel Section sends signals back to the Microprocessor Unit regarding which lift function it is carrying out, ie moving up, moving down, opening or closing doors, door zone or locks made etc.

The Motor Panel Section also transmits signals to and receives signals from the shaft and car, these being locks and safety circuit signals from the shaft wiring, door operator, car gate and safety circuit signals from the car wiring.

Signals to and from the shaft and car are also transmitted and received by the Microprocessor Unit. These include landing calls, position indicators, position resets and fire switch etc, from the shaft wiring and car calls, position indicators, service switch, etc, from the car wiring.

Duplex operation is possible, as is connection to an 'EMU' remote monitory system. There is a separate manual detailing connection requirements etc, for these features.

High reliability, field proven industrial standard components are used throughout the system and are readily available from many sources.

The system has signal protection, where all external incoming signals are optically isolated and filtered. Motor Panel signals are normally at 110VAC and all other incoming signals are at 100VDC, with the exception of landing and car push feed..

The Microprocessor System regularly tests itself throughout its operation and in its program, if an error is detected the system will automatically reset itself.

Specific Fault Events which may occur during lift operation are recognised and recorded by the system.

#### 1.4 **PERFORMANCE CHARACTERISTICS**

##### 1.4.1 **Electrical**

System Input voltage: 400V ac + 10% - 10% 50/60 HZ.

Note: other voltages available - consult factory.

##### **Power Supply Module Voltages**

	<b>ONIX POWER SUPPLY</b>		
<b>Input Voltage</b>	9V (30VA)	19V (50VA)	75V (75VA)
<b>Fuse Ident</b>	9V	19V	75V
<b>Rating</b>	2V a/s	3A a/s	1A a/s
<b>Output Voltage</b>	+10V dc	+24V dc	+100V dc
<b>Fuse Ident</b>	10V	CAF LAF 24V	100V
<b>Rating</b>	1A	1A 1A 2A	500mA

**Note 1:** Fuses not denoted a/s are quickblow.

**Note 2:** The 5V supply is derived from the 10V supply via a voltage regulator fitted on the motherboard.

<b>CPU Card</b>	-	+5Vdc Power
	-	+10Vdc Power
<b>24 Input I/O Card (Calls)</b>	-	+5Vdc Power
	-	+24Vdc Power
	-	Each input signal is activated by ref to OV
<b>22 Outputs</b>	-	<b>Output Relays</b>
	-	Single contact per relay
	-	Contact Rating 5A at 250Vac
	-	Coil Voltage 24Vdc
<b>28 Input Card (All Other Inputs)</b>	-	+5Vdc Power
	-	+24Vdc Power
	-	Each input signal is sourced from 100Vdc (and must exceed 75Vdc) via Motherboard
<b>28 Output Board</b>	-	+5Vdc Power
	-	+24Vdc Power
<b>Display/Function Board</b>	-	+5Vdc Power
	-	+24Vdc Power
<b>Motherboard</b>	-	+24Vdc Power
	-	+10Vdc Power
	-	-Two/RS232 serial communications ports
	-	Output Relays
	-	Single contact per relay
	-	Contact Rating 5A at 250Vac
	-	Coil Voltage 24Vdc

#### Environmental Range

<b>Humidity Operating Range</b>	0-90% relative humidity (non-condensing)
<b>Temperature Operating Range</b>	5-40 deg.C ambient

#### 1.4.2 Mechanical

<b>Main Motherboard Assembly</b>	<b>Height</b>	223mm
	<b>Width</b>	260mm
	<b>Depth</b>	145mm
	<b>Weight</b>	4.5Kg



## 1.5 Microprocessor System Description

The Microprocessor System comprises a number of printed circuit cards, all of which are mounted on the motherboard. These are namely:

- a) The Motherboard itself which contains the basic pilot motion control relays and the inputs which go to and come from the Panel. It also contains the DJR journey timer and serial communication ports.
- b) The Central Processor Unit (CPU) board which contains the program, control components SW3, SW4, RESET PUSH and DIL switches are also mounted on the board for configuration purposes.
- c) A 24 way I/O board for call inputs and call acceptance outputs.
- d) A 28 way Input board for all other incoming signals (external and main panel).
- e) A 28 way Output board for driving the Motherboard relays.
- f) A display/function board which contains an LCD display for Position, EVENTS and parameter viewing. Four Pushbuttons for obtaining the above information and parameter adjustment.

## **SECTION 2**

### **INSTALLATION AND COMMISSIONING**

		<b>PAGE</b>
2.1	<b>General</b>	<b>9</b>
2.2	<b>Connector Access</b>	<b>9</b>
2.3	<b>Microprocessor/System Connection</b>	<b>10</b>
2.4	<b>Control Panel Switch-On</b>	<b>10</b>
2.5	<b>Microprocessor Switch-On</b>	<b>11</b>
2.6	<b>Call Entry</b>	<b>11</b>
2.7	<b>Homing</b>	<b>12</b>
2.8	<b>Timers</b>	<b>12</b>
2.9	<b>Stuck Push Button</b>	<b>12</b>
2.10	<b>Input/Output Test</b>	<b>12</b>
2.11	<b>Motherboard I/O Designations</b>	<b>12</b>
2.12	<b>Call Designations</b>	<b>14</b>
2.13	<b>I/O Card Designations</b>	<b>15</b>

#### **2.1 GENERAL**

The external wiring for the Microprocessor controlled system is as shown in Fig 2.0

All car and landing call pushes are at 24Vdc potential - switched to ground.

All other incoming wiring to the Unit are at 100 V dc and all outgoing wiring for Indicators are at 24 V dc .

#### **2.2 CONNECTOR ACCESS**

All external wiring to the ONIX is made to the Motherboard terminals.

## 2.3

### **MICROPROCESSOR CONNECTIONS TO THE SYSTEM**

(Ref. Fig 1.0)

- a) **Transformer/PSU Connections (mounted on the Motor Panel)**
  - i) **Transformer Input**  
The appropriate voltage tapping should be selected on the PSU transformer to suit the application.
  - ii) **PSU Outputs**  
Power Supply Unit outputs go via a separate loom to socket Con 3 on the Microprocessor Motherboard.

**Note: This is normally factory wired..**

## 2.4

### **CONTROL PANEL SWITCH-ON**

Before switching on for the first time, carry out the following procedure:

- a) Disconnect the power loom from connector Con 3 at the Microprocessor Motherboard.
- b) Pull all the plug-in Cards out approximately 12mm.
- c) Interrupt the supply to the transformer/PSU (this is done because at this stage microprocessor operation is not required).

Switch on the control panel and ensure that no 110 or 230 VAC wiring has been connected to any of the connectors on the right hand side or the bottom of the motherboard.

When the wiring has been fully checked out, switch off and then reverse the procedures a, b and c above.

## 2.5 MICROPROCESSOR UNIT SWITCH-ON

After switching on, the following checks should be made:

- a) i) The two power supply LED indicators (top left) should be illuminated, to show that the +5V and +24V are available at the Motherboard.
- ii) If there is an earth fault on CT1 or CT2 the 100V fuse will blow.  
(All fuses on the ONIX Power Supply are 20mm fuses).
- b) The LCD Display Board shows the position of the lift when it was last switched off. If not on a terminal reset with a door zone registered the lift will, after a short delay "Dive" to the bottom floor.
- c) The green LED on the CPU card designated "Loop" should flash continuously.
- d) For a short time the EVENT CODE will display "POWER ON RESET". It maybe over-ridden by a "LOST LAR" which remains displayed. A "LOST LAR" indicates that the lift has a primary safety circuit failure because the LAR relay is de-energised.
- e) On the I/O cards, any of the red LED's illuminated shows that an incoming signal is present (refer to Para 2.12 for signal notations). Any of the yellow LED's indicate that an output relay has been energised (refer to page 17).


## 2.6 CALL ENTRY (ELECTRICALLY AND VIA KEYPAD)

Car calls and landing calls can be entered by grounding any of the appropriate terminals. CC1 to CC8 for Car Calls and LU1 to LD8 for Landing Calls. If done correctly the corresponding output relay will energise and LED will light indicating that the call has been accepted.

Alternatively car calls can be entered using the ONIX LCD keypad. See section 2.6.1 for further details.

### 2.6.1 ACCESSING AND USING THE CALL ENTRY SUB-MENU

From the ONIX default display, press the "ENTER" button to access the main menu, shown as menu level 1 in figure 3.0. Press the "UP" button and the display will change to show "2 - CALL ENTRY". Pressing enter again causing the display to change giving a graphical representation of call acceptances for levels 1 - 8.



The illustration above shows the LCD display with a call accepted at level 4 and the cursor position is at level 5. Both "UP" and "DOWN" buttons may be used to move the cursor position from level 1 - 8 and pressing "ENTER" puts a car call in the system for that level. Pressing escape at any time will return to the ONIX default display. The entered car call will be subjected to the normal car call operation (ie. lift on normal operation, blank or secure floors, car call reject operation and so on).

### 2.7 HOMING

The lift will "Home" to the main floor (or a floor specified by the customer) when HOMEN is switched to on. See Section 3.2.1.

### 2.8 TIMERS

The timer T1 through T9 may be set to customer requirements via the menu software which makes use of the display board pushbuttons and the LCD. Details of their functions, ranges, increments and default settings may be found in Section 3.2.4.

### 2.9 STUCK PUSH BUTTON

The MPU automatically reads the input signal when a push button is pressed, memorises it and compares it with the previous input signal.

If both signals are the same the command is ignored by the system until the stuck button is released and re-operated.

## 2.10 MOTHERBOARD I/O DESIGNATIONS

### Motherboard Inputs

15 Opto-isolated inputs rectified and smoothed.

Direct input from control circuit (110/230V ac or 110V dc)

\*

### Main panel monitoring inputs

1	LAR	Normal control relay
2	MUP	Motion up relay / Contactor
3	MDN	Motion down relay / Contractor
4	SPX	Selector step switch
5	TTR	Test control relay
6	OC	Door open relay/contactor
7	CC	Door close relay/contactor
8	DOL	Door open limit
9	DCL	Door close limit
10	CG	Car gate contact
11	GL	Landing gate contact
12	MC	Main motion contactor/Delta (Hydraulic)
13	LU	Levelling up switch
14	LD	Levelling down switch
15	ERR	Drive failure (eg DJR, FDR) Traction - Shutdown and park with doors closed. Hydraulic - Return to bottom floor, shutdown and park with doors closed.

### Motherboard Outputs to main panel

#### Main panel pilot relays

1	LDL	Low speed time limit/Pump motor dealy
2	PUR	UP direction pilot
3	PDR	DOWN direction pilot
4	HSR	High speed pilot
5	LSR	Low speed pilot
6	LSC	Low speed buffer shorting contactor
7	SP01	Spare output pilot
8	DOPR	Door open pilot
9	DCLR	Door close pilot
10	NUG	Door nudging pilot

## 2.11 CALL DESIGNATIONS

### FULL COLLECTIVE

FLOOR	CAR CALLS	UP-LANDING CALLS	DN-LANDING CALLS
8	CC8		LD8
7	CC7	LU7	LD7
6	CC6	LU6	LD6
5	CC5	LU5	LD5
4	CC4	LU4	LD4
3	CC3	LU3	LD3
2	CC2	LU2	LD2
1	CC1	LU1	

### DOWN COLLECTIVE/NON SELECTIVE COLLECTIVE/APB

FLOOR	CAR CALLS	HALL CALL
8	CC8	LD8
7	CC7	LD7
6	CC6	LD6
5	CC5	LD5
4	CC4	LD4
3	CC3	LD3
2	CC2	LD2
1	CC1	LU1

NOTE: APB operation

Ensure DIL switch 1 position 5 is "ON" refer to section 3.2 - SWITCHES.

## 2.12 I/O CARD DESIGNATIONS

### INPUT CARD 1 - 28 OPTO-ISOLATED INPUTS

#### INPUTS 1 - 15 RECTIFIED AND SMOOTHED DIRECT INPUT FROM CONTROL CIRCUIT (110V AC/DC)

IP1	LAR	Lift on Normal
IP2	MUP	Up Direction Signal
IP3	MDN	Down Direction Signal
IP4	SPX	Selector Stepping Switch
IP5	TTR	Lift on Test
IP6	OC	Door Opening
IP7	CC	Door Closing
IP8	DOL	Door Open Limit
IP9	DCL	Door Close Limit
IP10	CG	Car Gate Contact/Landing Lock Contact
IP11	GL	Landing Gate Contact
IP12	MC	Main Motion Contactor/Delta(Hydraulic)
IP13	LU	Leveling Up Switch
IP14	LD	Leveling Down Switch
IP15	ERR	Error/Drive Failure (eg. DJR, FDR) Traction - Shutdown and park doors closed Hydraulic - Return to bottom floor, shutdown and park doors closed.

#### INPUTS 16 - 28 (100VDC SMOOTHED)

IP16	FSR	Fire Control Switch
IP17	SSR	Car Preference Switch
IP18	WS110	Weight Switch 110% (Overload)
IP19	WS95	Weight Switch 95% (By-Pass)
IP20	EMR	Emergency Return Switch
IP21	DCP	Door Close Push
IP22	BB	Light Beam Broken
IP23	SE	Safety Edge
IP24	DOP	Door Open Push
IP25	BFR	Bottom Floor Reset
IP26	TFR	Top Floor Reset
IP27	SI1	
IP28	SI2	



## 2.13 I/O CARD DESIGNATIONS

INPUT/OUTPUT CARD 2 - 24 OPTO-ISOLATED INPUTS  
- 24 RELAY OUTPUTS

Each Input/Output is 24V potential pulled to ground to activate, then held to ground by the on board relay, apart from CAF and LAF which are sourced from 24Vdc.

1	LAF	Landing Call Indicator Feed
2	CAF	Car Call Indicator Feed
3	LU7	Landing Up Call Floor 7
4	LU6	Landing Up Call Floor 6
5	LU5	Landing Up Call Floor 5
6	LU4	Landing Up Call Floor 4
7	LU3	Landing Up Call Floor 3
8	LU2	Landing Up Call Floor 2
9	LU1	Landing Up Call Floor 1
10	LD8	Landing Down Call Floor 8
11	LD7	Landing Down Call Floor 7
12	LD6	Landing Down Call Floor 6
13	LD5	Landing Down Call Floor 5
14	LD4	Landing Down Call Floor 4
15	LD3	Landing Down Call Floor 3
16	LD2	Landing Down Call Floor 2
17	CC8	Car Call Floor 8
18	CC7	Car Call Floor 7
19	CC6	Car Call Floor 6
20	CC5	Car Call Floor 5
21	CC4	Car Call Floor 4
22	CC3	Car Call Floor 3
23	CC2	Car Call Floor 2
24	CC1	Car Call Floor 1

**Note:** Shown for full collective - see page 14 for alternative Call Designations.

## I/O CARD DESIGNATIONS

OUTPUT CARD - 28 SOLID STATE OUTPUTS, 24V POTENTIAL THAT ARE PULLED TO GROUND TO OPERATE RELAYS MOUNTED ON MOTHERBOARD.

### CONTROL CIRCUIT OUTPUTS

OP1	LDL	Low Speed Time Limit/Pump Motor Delay
OP2	PUR	Up Direction Pilot
OP3	PDR	Down Direction Pilot
OP4	HSR*	High Speed Pilot
OP5	LSR*	Low Speed Pilot
OP6	LSC*	Low Speed Buffer Shorting Contactor
OP7	SPO1	Spare Output
OP8	DOPR	Door Open Pilot
OP9	DCLR	Door Close Pilot
OP10	NUG	Door Nudging Pilot

### EXTERNAL OUTPUTS

OP11	CGU	Car Gong Up
OP12	CGD	Car Gong Down
OP13	LSI	Lift in Service Indicator
OP14	BZR	Door Warning Buzzer
OP15	FCI	Fire Control Indicator
OP16	OLI	Car Overloaded Indicator
OP17	SO1	Spare Output 1
OP18	SO2	Spare Output 2
OP19	IU	Direction Indicator Up
OP20	ID	Direction Indicator Down
OP21	PI8	Position Indicator Floor 8
OP22	PI7	Position Indicator Floor 7
OP23	PI6	Position Indicator Floor 6
OP24	PI5	Position Indicator Floor 5
OP25	PI4	Position Indicator Floor 4
OP26	PI3	Position Indicator Floor 3
OP27	PI2	Position Indicator Floor 2
OP28	PI1	Position Indicator Floor 1

\*Where direct interface drive systems are used please see associated drive manual for functioning and sequence of these outputs.

### **SECTION 3**

#### **OPERATING PROCEDURES**

		<b><u>PAGE</u></b>
<b>3.1</b>	<b>Operation of the Controls and Significance of Visual Indicators</b>	<b>19</b>
3.1.1	Power Supply Unit	19
3.1.2	Display/Function Board	19
3.1.3	CPU Card	19
3.1.4	I/O Card	19
<b>3.1.5</b>	<b>Audible Indicators</b>	<b>20</b>
3.1.5.1	Engineering Code	20
3.1.5.2	Event Log	20
3.1.5.3	Limited Force Door Closing	20
3.1.5.4	Selfish User Buzzer	20
<b>3.2</b>	<b>Switches</b>	<b>21</b>
3.2.1	CPU and Configuration Switches	21
3.2.2	RESET Push Button	22
3.2.3	Door Disable and Prepare to Test Switches	22
3.2.4	Timers	23
3.2.5	Motherboard Features	25
<b>3.3</b>	<b>Normal Control (Simplex)</b>	<b>26</b>
<b>3.4</b>	<b>Fire Control</b>	<b>27</b>
<b>3.5</b>	<b>Service Control (Car Preference)</b>	<b>28</b>
<b>3.6</b>	<b>By-Pass (Weight Switch 95%)</b>	<b>28</b>
<b>3.7</b>	<b>Event Log</b>	<b>29</b>
<b>3.8</b>	<b>Event Messages</b>	<b>29</b>
3.8.1	How to access and use the Event Log Sub Menu	31
3.8.2	Recalling the Event Log	32
3.8.3	Engineers Entry	32
3.8.4	Clearing the Event Log	33
3.8.5	Event Code Description	34
3.8.6	Security Code	45

### 3.1 OPERATION OF THE CONTROLS AND SIGNIFICANCE OF INDICATORS

#### Visual Indicators (Fig 1.0)

#### 3.1.1 Power Supply Unit

Each voltage developed by the PSU has a red LED associated with it to indicate that power is available to the system. They also show that the relevant fuse is intact. The LED's are:

- +10Vdc
- +24Vdc
- +100Vdc

#### 3.1.2 Display/Function Board

- a) Event Code Display - This shows the EVENT CODE and displays it for approximately 5 seconds.
- b) Position Display - This displays the current position of the lift.

#### 3.1.3 CPU Card

- a) Red LED's (2) - These show the direction of travel of the lift, the top one being "Up" and the bottom one being "Down".
- b) Green LED (Flashing) - This is the "Loop" indicator and it indicates that the microprocessor is operating correctly.

#### 3.1.4 I/O Cards

- a) Red LED's - There is a number on each Input Card and an illuminated LED indicates that an incoming signal is present.
- b) Yellow LED's - There are 28 on the Output Card and an illuminated LED indicates that an Output output Relay is energised.

### **3.1.5 AUDIBLE INDICATORS**

#### **3.1.5.1 Engineering Code**

When the engineer enters the code, ie 'CODE 11' a 'bleep' warning will accompany it.

#### **3.1.5.2 Event Log**

A 'bleep' warning is initiated when an EVENT CODE is registered.

#### **3.1.5.3 Limited Force Door Closing (Nudging)(Event Code 15) (optional)**

Car mounted buzzer which sounds discontinuously if any of the following conditions occur.

- a) Four door reversals have occurred.
- b) Doors fail to close in 25 seconds due to being held open by the safety edge or, door open push.

#### **3.1.5.4 Selfish User Buzzer (Event Code 15)**

Car mounted buzzer sounds discontinuously to encourage occupants to let the lift go.

## 3.2 SWITCHES

### 3.2.1 CPU and Configuration Switches

In order to configure the processor an 8 way DIL switch is fitted (switch 1).

#### **Switch 1 (8 way)**

Positions 1 to 5 configure the total number of floors.

Position 1	(FL1)	Binary	1 floor
Position 2	(FL2)	Binary	2 floors
Position 3	(FL4)	Binary	4 floors
Position 4	(FL8)	Binary	8 floors

Eg: Position 1 and 3 being 'ON' would select an 1+4=5 floor application.

Position 5	(APB)	ON =	APB
		OFF =	full collective / down collective

The main floor is typically factory set to level No. 1. Position 6, 7 and 8 selects the homing floor offset.

(On Duplex Systems both must be set to the same level).

Position 6	(HO1)	Binary	1 floor offset
Position 7	(HO2)	Binary	2 floor offset
Position 8	(HO3)	Binary	4 floor offset

Eg: Position 6 and 7 being on would select the homing floor offset to the floor 1 + 1 + 2 = 4.

In order to set some of the other built-in functions a 8 way DIL switch is fitted (switch 2).

### **Switch 2 (8 way)**

Position 1 invokes the homing feature

Position 1	(HOMEN)	ON	=	homing enabled
		OFF	=	homing disabled

Position 2 invokes the lift self test feature

Position 2	(LISEN)	ON	=	lift self test enabled
		OFF	=	lift self test disabled

Position 3 invokes the antinuisance feature

Position 3	(ANUEN)	ON	=	antinuisance enabled
		OFF	=	antinuisance disabled

Position 4 invokes the door nudging feature

Position 4	(NUGEN)	ON	=	door nudging enabled
		OFF	=	door nudging disabled

Position 5	}	Not used at this time
Position 6		

Position 7	(MOTION)	ON	=	lift motion enabled
		OFF	=	lift motion disabled

Position 8	(Master)	ON	=	master lift (Duplex only)
		OFF	=	slave lift (Duplex only)

### **3.2.2 Reset Push Button**

This momentary action push resets the processor.

### **3.2.3 Door Disable Switch and Prepare to Test Switch**

In order to invoke maintenance functions 2 toggle switches are fitted (switch 3 and 4).

SW3	(DDS)	ON = door operation disabled by processor
		OFF= door operation as normal dependent on mode (test, service, fire etc)

SW4	(PTT)	ON = responds to car calls only, doors park close in absence of car calls.
		OFF = calls accepted as normal dependent on mode (test, service, fire, etc)

### 3.2.4 TIMERS (SEE SECURITY CODE ENTRY - SECTION 3.8.6)

The timers T1 through T9 may be adjusted to customer requirements via the menu software which makes use of the display board pushbuttons and the LCD after entering the Security Code (see section 3.8.6). Their functions, ranges and increments are as follows:

NO	TIMER REF	DOOR TYPE	DRIVE TYPE			FUNCTION	RANGE	INCREM-ENT	DEFAULT SETTING		REMARKS
			SSD	2SD	V3F				VALUE	DELAY	
1	LST IST	N/A N/A		✓	✓	Low Speed Buffer Shorting Intermediate Speed Timer	0 - 4.5s 0 - 3s	0.3s 0.2s	0 0	0s 0s	When Using Direct Interface (TVL 201 Manual)
2	AOT GWB1	AUTO MANUAL		✓	✓	Advance Door Open (0 = Disable) Gate Open Warning "Off" Delay	0 - 4.5s 0 - 1m	0.3s 4.0s	4 1	1.2s 4s	Closed Loop Only
3	SDT	N/A									
4	ISR	AUTO	✓	✓	✓	Door Re-Open Delay	0 - 1.5s	0.1s	6	0.6s	A.C. Doors only
5	LTLR	N/A		✓	✓	Low Speed Time Limit	0 - 30s	2.0s	7	14s	
6	LDDT GWB2	AUTO MANUAL	✓	✓	✓	Landing Call Door Dwell Gate Open Warning "On" Delay	0 - 15s 0 - 1m	1.0s 4.0s	7 1	7s 4s	Collective Only
7	CDDT PREX	AUTO MANUAL	✓	✓	✓	Car Call Door Dwell Manual Gate Pause Extension	0 - 15s 0 - 15s	1.0s 1.0s	3 3	3s 3s	
8	FMT DHLD	N/A N/A				Sequential Start Interval Drive/Direction Hold	0 - 15s 0 - 1.5s	1.0s 0.1s	10 10	10s 1s	
9	BKRL	N/A			✓	Brake Release Time	0 - 3s	0.2s	2	0.4s	
A	N/A										
B	SPAR					Spare Timer					
C	SPAR					Spare Timer					

#### Notes

- 1) REFER TO MAIN CONTRACT DRAWINGS FOR APPLICATION
- 2) ✓ = USED ON DRIVE/DOOR TYPE
- 3) SEE KEY TO ABBREVIATIONS
- 4) THE FUNCTION MAY VARY IN SPECIAL CASES

KEY	DRIVE TYPE
SSD	SINGLE SPEED/SLEEP RING
2SD	TWO SPEED POLE CHANGE
V3F	VARIABLE VOLTAGE VARIABLE FREQUENCY/VECTOR
<b>DOOR TYPE</b>	
AUTO	ONLY USED FOR AUTOMATIC POWER DOORS
MANUAL	ONLY USED FOR MANUALLY OPERATED DOORS

#### ACCESSING AND USING THE TIMERS SUB-MENU

From the ONIX default display, press the "ENTER" button to access the main menu, shown as menu level 1 in figure 3.0. The display will change to show "1 - EVENT LOGGER". Provided the Security code has been entered, continue to press "ENTER" until the display changes to show "4 - ADJUST TIMERS". Pressing "ENTER" again will access the timers sub-menu and the system will invite the user to select the required timer T1 through T9. This may be done by using the "UP" and "DOWN" buttons as required. Pressing the "ESC" button at this point returns to menu level 1 without making any changes.



Given that the required timer has been selected, pressing "ENTER" will cause the display to change again, the upper line affirming the selection, and the lower line displaying the timers current setting and inviting amendments thus (for example);

**TIMER #6 (LDDT)  
SET TO : 8 NEW > 8**

Both "UP" and "DOWN" buttons may be used to alter the value indicated by "NEW >" until the desired value is reached. Subsequently pressing "ENTER" will store the new timer value and return immediately to menu level 2. Alternatively pressing "ESC" at any time, even after the value indicated by "NEW >" has been changed, will return to menu level 2 without altering the timer value.

### 3.2.5 Motherboard Features

#### DJR Timer

The DJR timer has two ranges:

S	20 - 60 seconds
L	40 - 120 seconds

The range is selected by jumper link (LK2). Fine adjustment is made by potentiometer P1 see Fig 1.0. DJR operation will cause the following sequence of events:

#### i) TRACTION

The contacts of the DJR relay are brought out to Motherboard terminals for use in the main panel circuitry to remove power from the motion contactor and relays. The hardware DJR timer will start timing when inputs MC and LAR are present and will be reset each time the input LU is operated. This contact, in series with any drive fault condition outputs (e.g. FDR), will also remove the ERR input into the motherboard, thus initiating a shutdown and removal from service. This mode requires jumper LK1 to be installed. See Fig 1.0.

Note: Since the DJR is reset at each floor it can be left at the factory setting (for Traction) of 25 seconds.

#### ii) HYDRAULIC

The contacts of the DJR relay are brought out to terminals for use in the main panel circuitry to remove power from the pump motor contactors S, D and M or PM1 and PM2 for DIRECT ON LINE STARTING. The hardware DJR timer will start timing when input MC and LAR are present. This contact, in series with MOL (n/c) and PFRR (n/o), will also remove the ERR input into the motherboard, thus initiating an emergency hydraulic recall sequence. This mode requires jumper LK1 to be removed.

Note: The DJR Timer should be set for the appropriate site full travel time.

### 3.3 NORMAL CONTROL (SIMPLEX) FULL COLLECTIVE

Momentary operation of a car or landing push will register that call and it's related call acceptance indicator will be illuminated.

**Car Calls:** Car calls will be intercepted in the order in which the destinations are reached, regardless of the sequence in which they were registered or the current direction of the lift. Car calls are cancelled on intercept at the appropriate landing.

**Landing Calls:** Landing calls are cancelled on intercept at the appropriate landing if the car is available to accept that particular call. When travelling up the car will stop at a landing for which a car call or an up landing call has been registered, but will not stop at a landing at which only a down landing call has been registered unless the down call is the highest outstanding call.

Similarly, when travelling down, the car will not stop at a landing at which only an up call is registered unless this is the lowest call outstanding. If the car stops at a landing at which both up and down call are registered, only the call for the direction in which the car is committed will be accepted (and cancelled). Should a car without registered car calls arrive at a landing at which both up and down calls are registered only the landing call for the last direction of travel will be accepted and the previous direction will continue. If no car call is inserted the doors will close after a preset interval and if there is then no landing call registered beyond this floor in the last direction of travel, the doors will re-open and cancel the landing call.

If the car fails to start in response to calls within 100 seconds all calls will be cancelled.

The doors are normally arranged to park closed. when fully open, momentary operation of any car call push will cause the doors to close immediately, otherwise the doors will close automatically after a preset time interval. The safety-edge contact or the light-ray contact connect directly in the the microprocessor unit. Opening of the doors cannot be prevented by continuous operation of car-push or door-close push.

### 3.4 FIRE CONTROL

Operation of a single pole Fire Control Switch installed on the main landing will immediately initiate Phase 1 Fire Control Return.

During Phase 1 Fire Control Return, the lift will return to the main floor as quickly as possible. The following operation will occur.

- 1) All calls will be cancelled except the main floor car call.
- 2) If the lift is travelling away from the main floor, the car will slow and stop at the next available landing, the doors will remain closed and following a short delay the lift will start to return to the main floor.
- 3) If the lift is travelling towards the main floor, the lift will continue to the main floor without interruption.
- 4) If the lift is at a landing with its doors open, the doors will close immediately and the lift will proceed to the main floor.
- 5) Throughout the Fire Service Control sequence the "Fire Control" indicator will be illuminated, landing calls will remain inoperative and the Light Ray (or other heat sensitive door devices) will be disabled.
- 6) Once at the main floor the fire fighting lift will park with its door open and Phase 2 Fire Service operation will begin. Note: A non fire fighting lift will close its door after a short delay to allow for the discharge of passengers and will not respond to any calls.

During Phase 2 Fire Service, the following operations will exist on the fire fighting lift;

- a) The doors will only open via constant pressure on the door open push, once they are fully closed. If the push is released before the doors have fully opened they will automatically close. Once the doors are fully open they will remain open until constant pressure of a call push causes them to close. If the call push is released before the doors are fully closed, the doors will re-open, all calls be cancelled and the lift will park with its doors open until a car push is re-operated.

- b) The safety edge will be disabled.
- c) Once the lift is moving, extra car calls can be inserted, but the lift will slow at the first call reached in its direction of travel and will cancel all calls upon stopping. The doors will remain closed until signalled to open by constant pressure operation of the door open push.
- d) The lift will only return to normal operation if the fire control switch is in its 'Off' position, the lift is at the main floor and the doors are fully open.
- e) Switching the fire control switch to 'Off' for a minimum of 5 seconds and then to 'On' again, at any time, will always cause the lift to return to the fire floor.

### **3.5 SERVICE CONTROL (CAR PREFERENCE)**

Service or car-preference control is established by operation of a switch in the car. All outstanding calls are cancelled and landing calls cannot be registered.

On SERVICE CONTROL the system is non-collective and all outstanding car calls will be cancelled whenever the doors fully open. If more than one car call push is operated simultaneously then the car will travel to the nearest call and all calls will be cancelled when the doors open.

### **3.6 BY-PASS (WEIGHT SWITCH 95%)**

If the car is fitted with a load sensing switch and this switch is closed when the doors are closing, then the by-pass feature operates so that the car cannot stop for intermediate landing calls and will only stop at the first car call encountered. Acceleration or retardation cannot cause inadvertent operation of the by-pass feature.

### 3.7 EVENT LOG

The event log may be inspected via the menu software which makes use of the display board pushbuttons and the LCD.

The event log sub-menu provides for the following three options.

- 1) Display events, event positions, their frequency and time elapsed.
- 2) Allows the Engineer to make an "electronic note" of their attendance.
- 3) Allows the Engineer to clear the log if required.

### 3.8 THE EVENT MESSAGES

#### AS DISPLAYED.....

- (0) POWER-ON RESET
- (1) LOST LAR
- (2) WATCHDOG RESET
- (3) NOT IN DOOR\_ZONE
- (4) D/OPEN PR. T/OUT
- (5) GL LOST : STOPPED
- (6) GL LOST : HI-SPEED
- (7) GL LOST : LO-SPEED
- (8) PRE-LOCK FAIL
- (9) D/CLOSE PR T/OUT
- (10) 110% OVERLOAD
- (11) ENGN'R ATTENDED
- (12) CALL T'FD/CNCL'D
- (13) NOT USED
- (14) MULT START FAILS
- (15) DOOR NUDGING
- (16) RAM FAILURE
- (17) STACK ERROR
- (18) SELF-TEST ERROR
- (19) EPROM FAILURE
- (20) FRONT SE OVERTIME
- (21) START FAILURE
- (22) NOT USED
- (23) NOT USED
- (24) NOT USED
- (25) END OF EVENT LOG
- (26) LOST CAR PUSH FD
- (27) LOST LDG PUSH FD
- (28) NOT USED
- (29) EMERGENCY SUPPLY
- (30) TIMER VALUE ERR.
- (31) GT LOCKS BRIDGED
- (32) GATE CLOSE FAULT
- (33) LTLR TIMEOUT
- (34) STUCK LEVELLER

#### VERBOSE DESCRIPTION.....

- CPU has reset after power-up or "reset" button pushed (note 1)  
Lift Available Relay de-energised  
CPU reset after power-up, "reset" push or program fail (note 1)  
Lift stopped outside door zone  
Door opening protection fault  
Gate lock fault whilst the lift was idle  
Gate lock tipped whilst the lift was on high speed  
Gate lock tipped whilst the lift was on low speed  
Gate pre-lock failure  
Door closing protection fault  
Weight switch indicates 110% of full load  
Engineer made note of a previous visit  
Call transferred or cancelled
- Multiple start failures  
Limited force door closing in operation  
CPU Non-Volatile Random Access Memory Failure  
CPU NVRAM or program failure  
Lift-in service self-test error  
CPU program failure  
Safety edge is holding the doors open for too long  
Lift has failed to start
- There are no further event log entries  
The feed to the car push has been lost  
The feed to the landing push has been lost
- Normal power supplies are off-line  
CPU has reset the system following memory corruption  
Gate lock signal present after doors have opened  
Gate lock signal not present after doors have closed  
Lift has taken excessive time to obtain floor level  
Levelling proximity/relay contact operated incorrectly

(35)	DRIVE ERROR	A drive monitor device has led to motor power removal
(36)	STUCK CAR CALL	A car push is stuck or is being held in
(37)	STUCK DOWN CALL	A landing down push is stuck or is being held in
(38)	STUCK UP CALL	A landing up push is stuck or is being held in
(39)	NOT USED	
(40)	NOT USED	
(41)	NOT USED	
(42)	* TEST CONTROL *	The lift is currently under Engineer's test control
(43)	NOT USED	
(44)	NOT USED	
(45)	NOT USED	
(46)	NOT USED	
(47)	NOT USED	
(48)	SE COMMS FAILURE	Communications failure
(49)	NOT USED	
(50)	NOT USED	
(51)	NOT USED	
(52)	NOT USED	
(53)	NOT USED	
(54)	NOT USED	
(55)	NOT USED	
(56)	NOT USED	
(57)	NOT USED	
(58)	M-G SET SHUTDOWN	M-G set shutdown switch
(59)	* LOBBY RETURN *	Lift on Lobby Return
(60)	NOT USED	
(61)	NOT USED	
(62)	LEVELLER/DIR ERR	Leveller or direction error
(63)	NOT USED	
(64)	NOT USED	
(65)	NOT USED	
(66)	FB LOST: HI SPEED	Feedback failed whilst the lift was on high speed
(67)	FB LOST: LO SPEED	Feedback failed whilst the lift was on low speed
(68)	NOT USED	
(69)	LANDING INHIBIT	Set if Landing Calls Disabled due to DDS or PTT
(70)	* FIRE SERVICE *	Lift on Fire Service
(71)	* SPECIAL SERVICE *	Lift on Special Service
(72)	DISPATCH FAILURE	Dispatcher failure
(73)	NORMAL OPERATION	Lift in Normal Operation

Note (1) - The **ONIX** does not discriminate between a system reset following restoration of the power supply, or a system reset caused by manual operation of the "reset" pushbutton on the CPU card - either will result in "**POWER-ON RESET**" and "**WATCHDOG RESET**" entries being made respectively in the event log.

Whenever one of these events occurs, the system displays the appropriate event message for 4 seconds and bleeps a warning. The event and the corresponding position of the lift are appended to the event log, which is held in non-volatile memory, so that the contents are maintained even if power is lost.

If the new event and the position of the lift match the last entry in the log, and this new event has occurred within the same 24 hour period, then instead of appending a new distinct event, the system adds 1 to the "event frequency" counter associated with the last event. This counter therefore clocks up the number of occurrences of the "same" event within 24 hour periods.

Associated with each event in the log is another portion of non-volatile memory which is incremented approximately every 24 hours. Thus it may be determined how many days ago an event occurred.

**Note:** Event **"GT LOCKS BRIDGED"** (Gate Locks Bridged) - The control panel may be fitted with "Pre-Flight" lift safety enhancement software.

If the lift lies in an unsafe condition due to a short circuit in the safety circuit wiring, trailing cables, terminal connections etc, relative to the door interlock circuitry. Pre-Flight will prevent movement (please refer to paragraph 3.8.5).

For this feature to operate effectively that all door and lock status signals are working correctly otherwise unnecessary "lockups" may be experienced.

**Note:** Pre-Flight is only enabled on controllers with suitable door operators. Please refer to Event Log on door for confirmation.

The event log is capable of holding up to 50 events. Appending another entry will cause information about the oldest event to be lost.

### 3.8.1 HOW TO ACCESS AND USE THE EVENT LOG SUB-MENU

From the ONIX default display, press the "ENTER" button to access the main menu, shown as menu level 1 in figure 3.0. The display will change to show "1 - EVENT LOGGER". Subsequently pressing "ENTER" again will access the event log sub-menu, shown as menu level 2 in figure 3.0.

From here the "UP" and "DOWN" buttons may be used to select one of the 3 options available, "ENTER" may be used to initiate an option, or "ESC" may be used to return to the next-highest menu level, which in this case is level 1.



### 3.8.2 RECALLING THE EVENT LOG

Recalling the event log does not interfere with normal lift service and may be done at any time provided the supply is available. Whilst the event log is being inspected, new events are still recognised, displayed for 4 seconds with an accompanying bleep, and appended to the log.

From the event log sub-menu, select "1 - **DISPLAY EVENTS**" and press "ENTER". The LCD will change to indicate the latest event, it's number in the event log and the position of the lift when the event occurred. Please note that this will not necessarily be the present position of the lift.

Pressing "ENTER" toggles the display to show the frequency of the event and the number of days since its occurrence, rather than the event number and position as described above. Pressing "ENTER" again toggles back to showing event number and position.

The "UP" and "DOWN" buttons enable inspection of the event log in both directions, with the "DOWN" button enabling inspection of increasingly earlier events, ie. those having lower event numbers and the "UP" button enabling inspection of increasingly recent events. Pressing "DOWN" whilst currently looking at information about event number 1, will result in the reminder message \*\*\*\* **END OF EVENT LOG** \*\*\*\* being displayed.

Whilst inspecting the event log as described above, pressing "ESC" at any time will return to the event log sub-menu.

### 3.8.3 ENGINEER'S ENTRY

At any time during a lift inspection or repair, the Engineer may record their attendance by appending an entry to the event log. This may be done by selecting "2 - **ENGR'S ENTRY**" from the event log sub- menu and pressing "ENTER".

The LCD will change to display "**LOG ATTENDANCE?**", and the system will wait for either the "ESC" or "ENTER" buttons to be pressed. At this point pressing "ESC" will return to the event log sub-menu without changing the event log. Alternatively pressing "ENTER" will log the event in the usual way, the system displaying the event for 4 seconds and issuing an accompanying bleep. This recorded attendance will now form the latest event in the event log.

Upon the next inspection of the event log, perhaps during their next visit, the Engineer will be able to easily determine which events have occurred since their log entry was made.

#### 3.8.4 CLEARING THE EVENT LOG

It may be useful at times to clear the event log, perhaps following lift inspection or repair, or simply to avoid cluttering the log unnecessarily. This may be done by selecting "3 - CLEAR LOG" from the event log sub-menu and pressing "ENTER".

The LCD will change to display "CLEAR EVENT LOG?" and the system will wait for either the "ESC" or "ENTER" buttons to be pressed. At this point, pressing "ESC" will return to the event log sub-menu without clearing the event log. Alternatively pressing "ENTER" will clear the log, the system will issue an acknowledging bleep and return immediately to the event log sub-menu.

Inspection of the event log, after clearing it, will simply result in the \*\*\*\* END OF EVENT LOG \*\*\*\* message being displayed.

### 3.8.5 Event Code Description

**(N) = Code Number**

**[EVENT] = As displayed on LCD (if fitted)**

**(0) [POWER ON RESET SEQUENCE]**

When the lift is switched on, the Microprocessor Unit (MPU), will begin its reset routine and store it in the event queue and then enter the lift program. The MPU can also be manually reset at any time by operation of the "Reset" Push on the CPU card.

**(1) [LOSS OF LAR]**

The LAR Relay (Lift Available Relay), on the motor panel provides this signal to the MPU. Whenever LAR Relay is de-energised, for example, due to the stop switch being operated, or the lift switched to maintenance control, the event will be displayed.

The event will remain displayed while this situation continues to exist. All car and hall calls will be cancelled and the "LSA" (Lift Service Available) indicator will be off. (This LSA indicator is only provided when requested).

**(2) [WATCHDOG RESET]**

This indicates that the MPU was unable to function properly through part of the lift program, such that it gets "stuck" and nothing else gets done. (Under normal circumstances this is unlikely to occur, but it is included for completeness).

After a short delay, the "Loop Flag Monitor" will deliberately reset the MPU. The MPU will again enter its reset routine, record the event and re-enter the lift program.

Part of the reset routine checks to see whether the call to reset was made by the "Loop Flag Monitor" circuit. If true, the MPU will also record the event.

**(3) [NOT IN DOOR ZONE]**

Here an attempt has been made by the MPU, to pilot open the doors but the "Door Open Contactor" (OC), has not energised. After a short delay and the Door Zone Relay" (DZ) not energising, the event will be recorded and the MPU will then seek another car or hall call elsewhere, to send the lift to.

This fault, for example, could be caused by a gate lock tip on low speed, or "Low Speed Time Limit" (LTLR) time-out.

**(4) [D/OPEN PR.T/OUT]**

This is when the door has failed to finish opening within 25 seconds. The event will be recorded, the MPU will stop piloting the "Door Open Contactor" (OC), and the "LSA" indicator will be cancelled. After a short delay the MPU will pilot the doors to close, so that the lift may move to another floor.

This fault, for example, could be caused by an obstruction in the landing door track.

**(5) [GL LOST : STOPPED]**

The lift is idle with the doors closed and with the gate locks made up. If a gate lock is then broken, the event will be recorded. The event will remain displayed while this situation continues to exist. This event can occur through excessive gate lock bounce, or by someone opening a landing door (not necessarily at the same floor as the lift's position).

**(6) [GL LOST : HI-SPEED]**

Tipping a gate lock on high speed will cause the lift to stop immediately. The MPU will record the event in the log.

After a short delay, the lift will re-start provided that the gate lock has re-made. If the gate lock is still broken, the event (GL Lost: High Speed), will be recorded as well.

**(7) [GL LOST : LO-SPEED]**

Tipping a gate lock on deceleration or slow speed will cause the lift to stop immediately. The MPU will record the event. After a short delay, the lift will try to open the doors, (since it is most likely that the lift was intercepting that floor, in response to a call registered there). If the lift is in the door zone, the doors will open.

If the lift is not in the door zone, a code (3) will be generated. The lift will then Re-start provided that the gate lock is re-made and there are calls elsewhere. If the gate lock is still broken, a code (5) will also be generated.

**(8) [PRE-LOCK FAIL]**

In this case, the lift is in the door zone, but unable to move in response to a call because of lock failure. The event will be recorded and the lift will re-open its doors in order to make another attempt to close and make up the gate lock.

After three unsuccessful attempts to start, the lift will then park with its doors open and a code (14) will be generated.

**(9) [D/CLOSE PR T/OUT]**

This is when the doors have failed to close within 25 seconds. The event will be recorded, the doors will reverse and park open and all calls will be cancelled. The "LSI" indicator will also be cancelled.

Prior to this situation occurring and if there are calls present, the MPU will reverse the doors if they failed to finish closing within 7 seconds, (without a code "9" generated or call loss etc). Three attempts are made to close within 10 seconds and then the doors will go for the full 25 seconds to close.

Following a door closing protection fault, the doors will park open and will only close again if a car or hall call is operated. If a door closing protection fault occurs again, the lift will then only respond to car calls.

This fault may be caused by an obstruction in the door track, or persons reluctant to move clear of the doors.

**(10) [110% OVERLOAD]**

Where the input WS110 is active the MPU will record the event, cause the doors to re-open and refuse to close until the load is reduced, also the OLI output (Car Overload Indicator) will be on.

**(11) [ENGN'R ATTENDED]**

See section 3.8.3.

**(12) [CALL TFD/CNCL'D]**

If the lift has not moved in response to calls present for 45 seconds, hall calls to which it should have attended will be released to the other lift (if one exists), the event is recorded and the "LSI" indicator will be cancelled.

If "[DOOR NUDGING]" feature has been specified, the MPU will sound a "Selfish User Buzzer" discontinuously (if fitted), in the lift car, in order to encourage the occupant to let the lift go.

If the lift still has not moved in response to the calls present for over 100 seconds all car calls will be cancelled. The buzzer will stop and the "LSI" indicator will remain cancelled. If the lift is operating as a simplex, all hall calls will be cancelled as well.

**(13) NOT USED**

**(14) [MULT START FAILS]**

After three successive pre-lock failures code (8), or three start failures code (21), all car calls will be cancelled, hall calls released, the "LSI" indicator cancelled, and the event recorded.

The lift doors will park open and will only close again if a car or a hall call is operated. If another code (14) is again generated, following a further three unsuccessful attempts to start, the doors will again park open, but will only respond to car calls.

**(15) [DOOR NUDGING]**

This feature is only available if the door operator is suitable. Provided that there are calls present, limited force door closing will come into operation if the doors are held open for over 40 seconds by safety edge or door open push, or if there have been 6 door reversals caused by the safety edge, light-ray etc.

A buzzer will sound discontinuously in the lift car, and the doors will close under limited force disregarding safety edge or light-ray operation. (The door open push is still effective in reversing and holding open the doors, but the doors will start closing immediately the door open push is released).

If the doors fail to finish closing after 15 seconds, so that the lift can move, door close protection will operate and code (9) will be generated. The doors will then reverse and park open (see code (9)).

**(16) [RAM FAILURE]**

The MPU has found fault with the integrity of its RAM. (included for completeness).

**(17) [STACK ERROR]**

The MPU has found fault with its "Book Keeping" and has reset its "Stack Pointer". (Included for completeness).

**(18) [SELF TEST ERROR]**

If the lift has been idle for more than 10 minutes, it will test itself by going to an adjacent floor and returning, seeking a . . . (lift moving - lift stopped - doors opening) . . . sequence of events. If this sequence does not occur within defined time limits, the "LSI" is cancelled. Another attempt is made after a further 10 minutes of idleness for confirmation.

If all is well, no further attempts will be made. If another failure occurs the event is recorded, the doors will park open, and the lift will only try to respond to car calls. The lift will automatically test itself if the lift has been moving or has its doors open for an unusually long time.

Code (18) is also generated if any other condition should cause the "LSI" indicator to illuminate.

**(19) [EPROM FAILURE]**

The MPU has added up all its program instructions and data and the resultant number does not match with a "Checksum" number also fixed into the program. (Included for completeness).

**(20) [SE OVERTIME]**

If the lift doors are held open by continuous operation of the safety edge for more than 15 seconds, the event is recorded.

**(21) [START FAILURE]**

The MPU has signalled for the lift to start and the lift has not done so. After a short delay, the lift doors will re-open and the event is recorded. After three unsuccessful attempts to start, the lift will then park with its doors open and event code (14) will be generated.

This fault, for example, could be caused by operation of the "Phase Failure and Reversal Relay" (PFRR), or the Motor Overload Trip.

**(22) NOT USED**

**(23) NOT USED**

**(24) NOT USED**

**(25) [END OF EVENT LOG]**

There are no further event log entries.

**(26) [LOST CAR PUSH FD]**

If the feed to the car pushes is lost, which could be caused by blown CAF fuse, the event is recorded. The lift will run in bus stop routine and be removed from group.

**(27) [LOST LDG PUSH FD]**

If the feed to the landing pushes is lost, which could be caused by blown LAF fuse, the event is recorded the lift will run in bus stop mode and respond only to car calls.

**(28) NOT USED**

**(29) [EMERGENCY SUPPLY]**

Indicates that normal power has been replaced by emergency power. In this condition the doors will park in the open position until the lift is requested to return to the main floor by the sequential return unit.

**(30) [TIMER VALUE ERR]**

The MPU has found corruption of values within "RAM" and will initiate a full RESET of the system.



**(31) [GT LOCKS BRIDGED] (PRE-FLIGHT)**

If a gate lock signal is present after the doors have finished opening then the gate locks are assumed to be bridged.

In this event several things occur:

- i) Lift movement on normal service is inhibited.
- ii) Landing, Car and homing calls are cancelled/disabled.
- iii) Service control and Prepare to test feature are all disabled.
- iv) Emergency recall is disabled.
- v) Fire service is disabled, if not already operating in phase II mode. If phase II is active then the PRE-FLIGHT check is disabled.
- vi) During dormant parking on hydraulic systems the PRE-FLIGHT check is disabled.

**(32) [GATE CLOSE FAULT]**

During a normal closing cycle of the doors a contact of the door closing relay is fed back into the microprocessor. If, having initiated a door closing cycle (ie, operated DCLR), the feedback signal is not present within 1 second, then the doors will be reversed and will open. The lift will then only respond to car calls.

**(33) [LTLR TIMEOUT]**

If during the slowing cycle the lift has taken an excessive time to obtain floor level the MPU will cause the direction to be lost, thus stopping the lift, the event is recorded the lift will be reset by a car call or MPU reset.

**(34) [STUCK LEVELLER]**

If during running the MPU considers a proximity/relay contact in the levelling circuit to be operated at a time when it should not be operated, the event is recorded and advance door opening will be inhibited. The check is performed on each run.

**(35) [DRIVE ERROR ]**

This signifies that a manual reset device has tripped (ie, DJR or FDR) and that power has been removed from the motor circuitry on the controllers. For traction lift applications the MPU will shutdown and not accept any further calls. For hydraulic lift applications the MPU will initiate a downwards dive. Once at the bottom floor the lift will park with its doors closed after allowing any passengers to alight. The DOP will remain operative in all instances providing the lift is in a door zone.

**(36) [STUCK CAR CALL]**

If one car push is not released within the expected time, it will be presumed stuck. The call will be ignored in future until it is released and reinserted, the fault is recorded along with the floor level that is affected.

**(37) [STUCK DOWN CALL]**

Similar to (36) except the call is a down landing call.

**(38) [STUCK UP CALL]**

Similar to (36) except the call is a up landing call.

**(39) NOT USED**

**(40) NOT USED**

**(41) NOT USED**

**(42) [TEST CONTROL]**

Indicates that the control system is in "Test control mode", ie. Car top control or Panel test. During this time no calls will be accepted and all features such as Fire or Service control are disabled.

**(43) NOT USED**

**(44) NOT USED**

**(45) NOT USED**

**(46) NOT USED**

**(47) NOT USED**

**(48) [SE COMMS FAILURE]**

This event is recorded if communication fails between the ONIX and the Shaft Encoder unit (if fitted).

**(49) NOT USED**

**(50) NOT USED**

**(51) NOT USED**

**(52) NOT USED**

**(53) NOT USED**

**(54) NOT USED**

**(55) NOT USED**

**(56) NOT USED**

**(57) NOT USED**

**(58) [MG SET SHUT DOWN]**

On DCVV applications this event is recorded for reference.

**(59) [LOBBY RETURN]**

Indicates that the system is in LOBBY RETURN mode. This requires an external signal LRET to return the lift to the main floor. All hall calls are cancelled or transferred, all remaining car calls are answered, then the lift will return to the main floor and remain there until the LRET is released.

**(60) NOT USED**

**(61) NOT USED**

**(62) [LEVELLER/DIR ERR]**

If the LU/LD signals are received by the MPU in the incorrect sequence, the event is recorded and at what level. On some drive applications, ie. Open Loop VVVF, it is important to know that the lift is travelling the expected direction. The sequence in which the LU/LD signals are received can determine the actual direction of the car, ie. Travelling Up: LU, LU AND LD, LD  
Travelling Down: LD, LD AND LU, LU.

The event may also be triggered if the LU/LD overlap is incorrect.

**(63) NOT USED**

**(64) NOT USED**

**(65) NOT USED**

**(66) [FB LOST : HI SPEED]**

This event is recorded if the MPU losses the direction or MC feedback from the main panel while the lift is travelling on high speed.

**(67) [FB LOST : LO SPEED]**

This event is recorded if the MPU loses the direction, or MC feedback from the main panel while the lift is travelling on low speed.

**(68) NOT USED**

**(69) LANDING INHIBIT**

Door disable or Prepare to test activated (LOSI)

**(70) [FIRE SERVICE]**

Indicates that the system is in Fire Service mode. See section 3.4 for further information.

**(71) [SPECIAL SERVICE]**

Indicates that the system is in Special Service mode. See section 3.5 for further information.

**(72) [DISPATCH FAILURE]**

Indicates that the MPU has lost communication with the dispatcher, the lift will continue to respond to car calls and stop at alternating floors in the Up and Down direction to take passengers that may be waiting.

**(73) [NORMAL OPERATION]**

Indicates that the system is in normal operation.

### 3.8.6 Security Code

The Menu System has the added feature of a user defined four digit Personal Identification Number. The purpose of this is to protect the adjustable parameters from being tampered with by unauthorised personnel.

When the panel is supplied from the manufacturer the **PIN** number is zero, therefore allowing the new user to input their own four digit number. To input the **PIN** you must select the security code menu, which is level 3, and follow the instructions on the display.

To enter the numbers, use the **UP** or **DN** button to select the required numeral 0 - 9 and press Enter to confirm. The next digit is automatically selected. If you change your mind at any time before all four digits have been entered, you may Exit the process by pressing the ESC button. If all four digits are entered you will be prompted with **\*CORRECT\***.

The number you have just entered is now set and stored, even if the controllers power is removed.

You will now have access to Menu levels above level 3. The Menu levels above are only available for a set time (30 mins) and will be inhibited after the timer expires. To gain access you must re-enter your chosen **PIN** as above.

If you wish to change your **PIN** at any time you must enter or have already entered your current **PIN** and from the **PIN** entry display (**PIN : \*\*\*\***) press the **UP** and **DN** buttons simultaneously. This will clear your current **PIN** and you will be prompted by **\*CLEARED\*** and will allow you to enter a new **PIN**.

If at any time you enter a **PIN** and are prompted **\*INCORRECT\***, the **PIN** you have entered does not correspond to the one stored.

**SECTION 4**

**TECHNICAL DESCRIPTION**

		<b><u>PAGE</u></b>
4.1	<b>Motherboard</b>	46
4.2	<b>Power Supply</b>	46
4.3	<b>CPU Card</b>	47
4.4	<b>Watchdog-Loop Flag Monitor</b>	47
4.5	<b>Audible Warning</b>	47
4.6	<b>Pushbuttons</b>	47

#### 4.1 MOTHERBOARD (FIG 1.0)

The Motherboard contains sockets to mount the plug-in boards:

1. Processor
2. I/01, I/02, I/03

It also contains the Control Inputs and Outputs to the Panel, the Double journey Relay and external terminals.

#### 4.2 POWER SUPPLY

The Power supply Module is mounted directly on the top of the mains transformer to conserve panel space. AC voltages are connected directly from the transformer into the PSU module where they are fused, rectified, filtered and fused again. Each output of the PSU has an LED to indicate that it is operating correctly.

The Output Voltages of the PSU module are as follows:

- +10vDC            Input to the 78s 05 +5v regulator on the Motherboard supplying power to the Microprocessor Logic circuits.
- +24vDC            Power for the relays on the I/O Cards etc.
- +100vDC           Power for the External Input signals

#### PSU Module Fuse Values (All fuses are 20 mm)

9Vac	2A	Anti-surge
19Vac	3A	Anti-surge
80Vac	1A	Anti-surge
+10Vdc	1A	Quick-blow
+24Vdc	2A	Quick-blow
+100Vdc	500mA	Quick-blow



#### **4.3 CPU CARD (CENTRAL PROCESSING UNIT)**

The CPU Card contains the 6809 Microprocessor, RAM, EPROM and all support circuitry. It also contains the configuration switches and PTT (prepare - to - test) and DDS (door disable) switches.

#### **4.4 WATCHDOG-LOOP FLAG MONITOR**

The end command of the main lift program instructs the MPU to go back to the start of the program, this loop continues servicing all the routines and signifies correct operation of the system. A Counter counts the number of loops completed and causes the LOOP FLAG indicator to flash.

If in any event the MPU stays in a particular routine, the LOOP FLAG indicator discontinues flashing and the fault is recognised by the LOOP FAILURE MONITOR which will reset the MPU, and cause it to re-enter the loop (EVENT CODE '0').

THE MPU, during the reset routine, tests to see if the LOOP FAILURE MONITOR had called for a reset, if so the MPU generates an EVENT CODE "2".

#### **4.5 AUDIBLE WARNING**

A warning bleep will occur in conjunction with the EVENT CODE display, whenever an event occurs in the microprocessor system.

#### **4.6 PUSHBUTTONS**

Four Pushbuttons, are situated on the front of the Event Log card which are used for adjusting timers and re-calling events which have occurred within the system and other special functions.

**SECTION 5**  
**OVERHAUL & REPAIR**

		<b><u>PAGE</u></b>
5.1	<b>Handling of EPROM's</b>	49
5.2	<b>Fault Finding Procedures</b>	49

## 5.1 HANDLING OF EPROMS

**WARNING** 27C256 EPROMS MOS DEVICES WHICH REQUIRE CAREFUL HANDLING IN THE REMOVAL AND INSERTION STAGE, AS THEY CAN EASILY BE DAMAGED BY STATIC ELECTRICITY.

To change EPROM - see instructions in back of manual.

## 5.2 FAULT FINDING PROCEDURES

### Initial Checks

- 1) Ensure all power supplies on MPU are operating satisfactory.
  - a) 100V dc supply LED illuminated on power board.
  - b) 24V dc supply LED illuminated on power board and on Motherboard.
  - c) 10V dc supply LED illuminated on power board.
  - d) 5V dc supply LED illuminated on Motherboard.

If the power supply LED's are extinguished, check the fuses on the power supply card (situated in holders mounted on the card). If fuses persist to blow, remove all cards and reinsert one card at a time until fault is localised to a card which can then be replaced.

- 2) Check loop flag is pulsing on CPU card proving that the MPU program is continually scanning its programme loop.

If this condition cannot be achieved then the CPU card should be replaced. Remember when replacing the card that the EPROM contained on the original card must be moved into the test replacement card, (EPROMS must have labels with contract details covering a transparent window, label must not be removed). If satisfactory operation of the loop flag indicator is not achieved then replacement EPROMS must be tried, and closer monitoring of the power supplies must be carried out, this time with a meter.

- 3) Having achieved pulsing operation of the loop flag attention should be turned to the I/O cards.
- 4) With all cards inserted into the motherboard the lift should be ready for initial operation.


Switch the lift to car top test and observe the LED signals on the I/O cards. Check that the selected I/O signals are "ON". If LED's are not as expected, then check voltage to terminals at inputs to motherboard to verify that external signals are correct. If I/O card LED's do not coincide with input terminal voltages then wiring should be checked or cards replaced to isolate fault.

- 5) Door open and close operation on normal service is controlled by output signals DOPR and DCLR respectively. With doors closed DCLR, GL and LU/LD if in door zone, should be illuminated. Operation of SE or DOP signal on normal service should operate DOPR signal to open the doors providing LU/LD signal is present (lift in door zone). When doors open first GL and then DOL are extinguished. If lift is on normal service then after approximately 7 seconds (adjustable by LDDT dwell timer) the doors should park closed.

**SECTION 6**


**ILLUSTRATIONS**

		<b><u>PAGE</u></b>
<b>FIG. 1</b>	<b>Component Positions On Motherboard</b>	<b>53</b>
<b>FIG. 2</b>	<b>General Wiring Schematic</b>	<b>54</b>
<b>FIG. 3</b>	<b>Overview Of Menu System</b>	<b>55</b>
<b>FIG. 4</b>	<b>Setting up of Single Floor Run</b>	<b>56</b>



DJR  
DOUBLE JOURNEY  
RELAY.  
RESET BUTTON AND LED  
AND POTENTIOMETER


MOTHERBOARD REVISION 'B'.  
FIG 1.0 COMPONENT POSITIONS ON MOTHER BOARD



MOTHERBOARD REVISION 'B'.  
 FIG 2.0 GENERAL WIRING SCHEMATIC (NON SPECIFIC)

NOTE.  
 IF INCANDESCENT BULBS ARE USED FOR CALL ACCEPTANCE, IT MAY BE NECESSARY TO FIT DIODES IN SERIES WITH THE BULBS .  
 PLEASE CONTACT THE FACTORY FOR FURTHER DETAILS.


5<sup>th</sup> MAY 1999





# FIG 4.0 SETTING UP OF SINGLE FLOOR RUN

ONLY APPLICABLE TO VVVF/VECTOR APPLICATIONS WHEN REQUIRED





## EPROM CHANGING INSTRUCTIONS

Severe electrical transient voltages can be generated during handling. These static voltages are ruinous when discharged into electrical components, i.e. EPROM's. Nylon or other static generating materials must not come in contact with EPROM devices and personnel should discharge themselves to ground prior to handling.

1. Switch controller power supply OFF.
2. Remove the J6809 CPU board from the Motherboard taking care not to damage the connector pins. To achieve this you must first remove the LCD panel from the motherboard via the front screws and pillars (Figure 1). Note the LCD panel and CPU board slide out together.




Figure 1. LCD Panel.

Note the 4 Screws on the LCD Panel's face. These have to be removed to get to the lower pillar screw underneath. The lower pillar screw must then be removed.

3. Remove the existing EPROM IC8 with a small screwdriver blade under one end of the pin socket. Ease it carefully, until it is nearly out of the board DIL sockets. Then grasp the EPROM with as many fingers in contact with as many pins of the EPROM as possible and transfer it straight to anti-static foam. Similar care should be taken when inserting the replacement EPROM onto the board DIL socket.
4. Fit the new EPROM ensuring that the notch is in the correct position according to Figure 2 below.
5. Replace the J6809 CPU board with care, make sure all pins are lined up with the connector before pushing the board into position, then switch controller supply ON.




Figure 2. J6809 CPU Board

### Replacement Software

If Contract consists of multiple like panels (e.g. Duplex, Triplex), ensure that all software supplied is fitted so all panels contain the same program release. Failure to do so may result with intermittent problems.